




How to read a Hydrawise Flow meter.

The Hydrawise flow meters comes in a metric reading called M³ which is Meters Cubed or 1000 Litres. (Conversion rate for US customers is 1 Litre is 3.78 US gallons)

Reading meters is about looking at the number that has past not the number that is coming up.

Reading the Meter



The dials are easy to read.

Start here

1. The number is **8** or 8,000 litres always read the last number as one most at the top of the dial.
2. The number is **2** so as we read it now it would be 8,200 litres then we continue clockwise around the meter.
3. The number would be **2** as it has not got to 3 yet so we are at 8,220 Litres
4. The number is **4**, so we are at 8,224 litres
5. The number is **7**, so the complete number is 8,224.7 litres

So we have a flow that has gone through the meter of 8,224.7 Litres. To calculate this into Gallons is easy $8,224.7 / 3.78 = 2175.84$ gallons.