

# ACC Controller Maintenance Radio Commands Summary

| Command  | Result  |
|--|---|
| [#ss]*aaa#nnn#[ttt]#                           | Start station #nnn for [ttt] HH:MM or global MR Time  |
| [#ss]*aaa#nnn*                                 | Stop station #nnn   |
| [#ss]*aaa##                                    | Sequential step up to next station  |
| [#ss]*aaa#*                                    | Sequential step down to previous station  |
| [#ss]*aaa#950#pp#[nnn]#                        | Semi-Auto start FC Program pp @ station #nnn  |
| [#ss]*aaa#950#pp*                              | Stop FC Program pp  |
| [#ss]*aaa#951#pp#[gg]#                         | Semi-Auto start FC Program pp @ SSG #gg   |
| [#ss]*aaa#952#cc#[ee]#<br>[#ss]*aaa#C#cc#[ee]# | Semi-Auto start Custom Manual Program #cc @ event #ee<br>SHORTCUT = C (mnemonic: <u>C</u> ustom Manual) |
| [#ss]*aaa#953#gg#[ttt]#                        | Start SSG #gg for [ttt] HH:MM or global MR Time   |
| [#ss]*aaa#953#gg*                              | Stop SSG #gg  |
| [#ss]*aaa#960*<br>[#ss]*aaa#D*                 | Stop all irrigation for FC<br>SHORTCUT = D (mnemonic: <u>D</u> elete)                                   |
| [#ss]*aaa#961*<br>[#ss]*aaa#B*                 | Pause all irrigation for FC<br>SHORTCUT = B (mnemonic: <u>B</u> reak)                                   |
| [#ss]*aaa#961#<br>[#ss]*aaa#B#                 | Begin / Resume all irrigation for FC<br>SHORTCUT = B (mnemonic: <u>B</u> egin)                          |
| [#ss]*aaa#998#                                 | Initiate Radio Transmit Test (5 second test)  |
| [#ss]*aaa#999#                                 | Communications Check to FC (OK Response)  |

## Legend

|      |  |
|------|--|
| [ ]  | Optional item – Default value is used if omitted<br>Not available in first release of Com Module               |
| Ss   | System ID (1-99). If system Maintenance Radio System ID is enabled, user MUST supply ID to operate the system. |
| aaa  | FC Address (1-999)   |
| nnn  | Station Number (1-99) (Allow for 3 digit station # in future)  |
| pp   | FC Program A through F (1-6) (Allow for 2 digit program in future)   |
| Cc   | Custom Manual Program Number (1-16)  |
| gg   | SSG Number (1-20)  |
| tttt | Run Time (1 to 6:00 HH:MM) (Allow for > 10hr runtime in future)  |
| ee   | Event # (1 to 50) within the Custom Manual Program   |